








$\varnothing 25$  B x2	$\varnothing 30$  C x1	$\varnothing 25$  D x5	$\varnothing 25$  E x1	$\varnothing 10$  F x1
$M10 \times 110$  G x1	 H x1	 I x1	$M6 \times 35$  J x2	$M6$  K x2
 L x2	 M x4	$M6$  N x2	 O x2	 P x2
$M6 \times 45$  Q x2	$M6$  R x4	 S x4	$M6$  T x4	

DEMO. PRODUIT









B137NM

outils nécessaires (non fournis)



T1	T2	h min. (mm)	h max. (mm)
a	a	2720	2800
a	b	2620	2700
b	b	2520	2600
b	c	2450	2500
c	c	2320	2400


 si $H < 2320$ alors $L = 2350 - H$




SAV

Si malgré toutes les précautions prises lors de la conception du produit, vous deviez rencontrer un problème, notre Service Après Vente reste à votre disposition. Du lundi au jeudi : de 8h00 à 17h00 et le vendredi de 8h00 à 15h00



33 (0)3 20 10 90 25



33 (0)3 20 10 37 89



be-sav@mottez.com

CONB137 18 108